




PDX535

ACTION WEBCAM

WITH TOUCH MUTE & PRIVACY COVER


OVERVIEW




1. Lens	2. Microphone	3. Signal indicator
4. Type C port	5. Mount bracket	6. 1/4 " Tripod nut
7. Mute key	8. Privacy cover slide nob	

MOUNT THE WEBCAM

1. Rotate the mount bracket and place the webcam on the computer monitor.
2. You also can mount the webcam to a tripod as you need.



OPERATE THE WEBCAM



- Plug the webcam into USB socket of PC or TV STB.
- Wait about one minute, webcam will install automatically.
- When video calling connect, the signal indicator will be turn on.
- When touch the mute key, video will pause and voice mute. indicator will be blink.touch again to recover.
- If not use for a long time, slide the privacy cover knob to close.

GETTING START WITH VIDEO CALLING

To take advantage of video calling, both you and the person you call must install video-calling application, such as Skype, Yahoo! IMessenger, Windows LiveIMessenger or Gmail.

As well as a USB camera and video calling application, both callers need;

- A computer with speaker(or a headset) and a microphone (the webcam has built-in microphone);
- A broadband Internet connection(e.g., DSL, T1, or cable);
- Please check your preferred video calling application requirements, (requirements may vary between different applications, but usually a minimum of 2Mbps upload speed is required);

QUESTIONS AND ANSWERS

Q: How do I know if my camera is recognized by the operating system?

A: Connect the camera in any USB2.0/3.0 port. Once the camera is connected, it takes a few moments before the camera is recognized. To ensure the camera has installed correctly, check the following: Under Control Panel > System and Security > System > Device Manager

Q: How do I know if my video calling application is using my webcam?

A: All video applications have an option setting to review the audio and video device. Using the video application, review the followings:

- The Audio selection to ensure the USB2.0 camera microphone is selected. If not, change the selection to USB2.0 camera.
- The Video selection to ensure the USB2.0 is selected. If not, change the selection to the USB 2.0 camera.

For more information,
please contact our support team:


support@porodo.net



PDX535

كاميرا الويب ذات الإجراء
مع زر الكتم اللمسي وغطاء الخصوصية


نظرة عامة




١. العدسة	٢. الميكروفون	٣. مؤشر الإشارة
٤. منفذ USB Type-C	٥. حامل التركيب	٦. براغي ترايبود بحجم ٤/١ بوصة
٧. زر الكتم	٨. مفتاح سحب غطاء الخصوصية	

تثبيت كاميرا الويب

١. قم بتدوير حامل التركيب وضع كاميرا الويب على شاشة الكمبيوتر.
٢. يمكنك أيضا تثبيت كاميرا الويب على حامل ترايبود حسب الحاجة.



تشغيل كاميرا الويب



. قم بتوصيل كاميرا الويب بمنفذ USB في الكمبيوتر أو جهاز تلفزيون STB.
. انتظر لمدة حوالي دقيقة واحدة، ستقوم كاميرا الويب بالتهيئة تلقائياً.
. عند إجراء مكالمة فيديو، سيتم تشغيل مؤشر الإشارة.
. عند لمس زر الكتم، سيتوقف الفيديو ويتم كتم الصوت. سيومض المؤشر. قم باللمس مرة أخرى للاستئناف التشغيل.
. إذا لم تستخدم الكاميرا لفترة طويلة،
قم بسحب مقبض غطاء الخصوصية لإغلاقه.

البدء في استخدام المكالمات الفيديو

للاستفادة من المكالمات الفيديو، يجب على الشخصين الاتصال بتهيئة تطبيق المكالمات الفيديو،
مثل Skype أو Yahoo! Messenger أو Windows Live Messenger أو Gmail.
بالإضافة إلى كاميرا USB وتطبيق المكالمات الفيديو، يحتاج الشخصان الاتصال بهما إلى: البدء في
استخدام المكالمات الفيديو

. جهاز كمبيوتر مع مكبر صوت (أو سماعة رأس) وميكروفون (الكاميرا لديها ميكروفون مدمج).

. اتصال إنترنت عريض النطاق (مثل DSL أو T1 أو كابل).

يرجى التحقق من متطلبات تطبيق المكالمات الفيديو المفضلة لديك (قد تختلف المتطلبات بين
التطبيقات المختلفة، ولكن عادة ما يتطلب الحد الأدنى من ٢ ميجابايت في الثانية لسرعة الرفع).

أسئلة وأجوبة

س: كيف أعرف ما إذا كانت الكاميرا معترف بها من قبل نظام التشغيل؟

ج: قم بتوصيل الكاميرا في أي منفذ ..USB٢.٠/٣.٠. بمجرد توصيل الكاميرا، يستغرق بعض الوقت قبل أن يتم التعرف على الكاميرا. للتأكد من تثبيت الكاميرا بشكل صحيح، تحقق من ما يلي: في لوحة التحكم < النظام والأمان > النظام < مدير الأجهزة.

س: كيف أعرف ما إذا كان تطبيق المكالمات الفيديو يستخدم كاميرا الويب الخاصة بي؟

ج: جميع تطبيقات الفيديو لديها إعداد خيار لمراجعة جهاز الصوت والفيديو. باستخدام تطبيق الفيديو ، قم بمراجعة ما يلي:

. تحقق من تحديد الصوت للتأكد من تحديد ميكروفون الكاميرا ..USB٢.٠. إذا لم يتم ذلك ، قم بتغيير

التحديد إلى كاميرا ..USB٢.٠.

. تحقق من تحديد الفيديو للتأكد من تحديد ..USB٢.٠. إذا لم يتم ذلك ، قم بتغيير التحديد إلى كاميرا USB ..

For more information,
please contact our support team:

support@porodo.net